





DREAM CURTAIN BATTERY MOTOR

191782









PROGRAMMING INSTRUCTIONS

Before starting the process of pairing a handheld remote/wall switch to a Dream motor, choose the channel to which it is to be paired. Channel Zero is reserved for simultaneously controlling all blinds paired to a remote and cannot be used for pairing, programming or other adjustments. If using a battery powered motor, ensure that it is sufficiently charged to complete the set-up process.

